

MaxiSys_Englon_V3.10 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Model	System	System Type	Read Codes	Erase Codes	Ecu Info.	Live Data	Active Test	Freeze Frame	Special Function
SC3 1.0L	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC3 1.0L	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
SC3 1.0L	Body Control System	Shanghai Hu gong body control system	●	●	●	●	●	○	0x89 0x57
SC3 1.0L	ABS	SABS MK70 ABS System	●	●	●	●	○	○	0x4E 0x15 0x16
SC3 1.0L	SRS	AUTOLIV Airbags	●	●	●	●	○	○	0x6B
SC3 1.0L	Immobilizer System	Immobilizer System (with UAES EMS)	●	●	●	●	○	○	
SC3 1.3L	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC3 1.3L	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
SC3 1.3L	Body Control System	Shanghai Hu gong body control system	●	●	●	●	●	○	0x89 0x57
SC3 1.3L	ABS	SABS MK70 ABS System	●	●	●	●	○	○	0x4E 0x15 0x16
SC3 1.3L	SRS	AUTOLIV Airbags	●	●	●	●	○	○	0x6B
SC3 1.3L	Immobilizer System	Immobilizer System (with UAES EMS)	●	●	●	●	○	○	
SC513T	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC513T	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
SC513T	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC513T	Engine System	Continental engine system	●	●	●	●	●	○	0x4C
SC513T	Automatic Transmission System	JACTO Automatic Transmission System (CAN)	●	●	●	●	○	○	0x62
SC513T	ABS	Bosch anti-lock braking system8	●	●	●	●	●	○	
SC513T	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
SC513T	ABS	Bosch anti-lock braking system8(K Line)	●	●	●	●	●	○	0x50 0x25
SC513T	SRS	Continental Airbag System	●	●	●	●	●	○	0x4C 0x5D
SC513T	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SC513T	Power Steering System	JTEKT EPS system	●	●	○	●	○	○	
SC513T	Instrument Panel System	Aerospace Hi-Tech Instrument	●	●	●	●	●	○	0x4C 0x70
SC515	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC515	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
SC515	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC515	Engine System	Continental engine system	●	●	●	●	●	○	0x4C
SC515	Automatic Transmission System	JACTO Automatic Transmission System (CAN)	●	●	●	●	○	○	0x62
SC515	ABS	Bosch anti-lock braking system8	●	●	●	●	●	○	
SC515	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
SC515	ABS	Bosch anti-lock braking system8(K Line)	●	●	●	●	●	○	0x50 0x25
SC515	SRS	Continental Airbag System	●	●	●	●	●	○	0x4C 0x5D

Model	System	System Type	Read Codes	Erase Codes	Ecu Info.	Live Data	Active Test	Freeze Frame	Special Function
SC515	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SC515	Power Steering System	JTEKT EPS system	●	●	○	●	○	○	
SC515	Instrument Panel System	Aerospace Hi-Tech Instrument	●	●	●	●	●	○	0x4C 0x70
SC615	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C 0x61
SC615	Engine System	Continental engine system	●	●	●	●	●	○	0x4C
SC615	Automatic Transmission System	JACTO Automatic Transmission System (CAN)	●	●	●	●	○	○	0x62
SC615	Automatic Air-conditioning Syst	Yanfeng visteon automatic A/C system	●	●	●	●	○	○	
SC615	ABS	Continental MK70 anti-lock braking system	●	●	●	●	●	○	0x63 0x15
SC615	ABS	Continental MK70 anti-lock braking system(K Line)	●	●	●	●	○	○	0x4E 0x15 0x16
SC615	SRS	TRW airbag system	●	●	●	●	○	○	0x64
SC615	Power Steering System	JTEKT EPS system	●	●	○	●	○	○	
SC615	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SC615	TPMS	TTE TPMS	●	●	○	●	○	○	0x36
SC615	Instrument Panel System	Deco combination instrument system	●	●	●	○	●	○	0x70
SC615	BMCS	Tire Pressure Monitoring and Security Control (BMCS) System	●	●	○	●	○	○	0x37
SC715	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC715	Engine System	Delphi MT22.1 engine system(K Line)	●	●	●	●	●	●	0x4C 0x40
SC715	Engine System	Delphi MT80 Engine System	●	●	●	●	●	●	0x4C 0x40
SC715	Engine System	Methanol fuel engine (479 Dongguan transmission)	●	●	●	●	●	○	
SC715	Engine System	Methanol fuel engine (4M Dongguan transmission)	●	●	●	●	●	○	
SC715	ABS	Bosch 8.0 anti-lock braking system	●	●	●	●	●	○	0x18 0x0B
SC715	ABS	Bosch anti-lock braking system8(K Line)	●	●	●	●	●	●	0x25 0x50
SC715	ABS	Bosch anti-lock braking system8	●	●	●	●	●	○	
SC715	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
SC715	ABS	Bosch anti-lock braking system9(K Line)	●	●	●	●	●	○	0x6B 0x25
SC715	SRS	Jinheng 4AB Airbags	●	●	●	●	○	○	
SC715	SRS	AUTOLIV Airbags	●	●	●	●	○	○	0x6B
SC715	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SC715	Body Control System	Shanghai Hu gong body control system	●	●	●	●	●	○	0x89 0x57
SC718	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
SC718	Engine System	Delphi MT22.1 engine system(K Line)	●	●	●	●	●	●	0x4C 0x40
SC718	Engine System	Delphi MT80 Engine System	●	●	●	●	●	●	0x4C 0x40
SC718	Engine System	Engine Delphi MT80 engine system	●	●	●	●	●	○	0x4C 0x40
SC718	Automatic Transmission System	DSI 6AT	●	●	●	●	○	○	
SC718	ABS	Bosch 8.0 anti-lock braking system	●	●	●	●	●	○	0x18 0x0B
SC718	ABS	Bosch anti-lock braking system8(K Line)	●	●	●	●	●	●	0x25 0x50

Model	System	System Type	Read Codes	Erase Codes	Ecu Info.	Live Data	Active Test	Freeze Frame	Special Function
SC718	ABS	Bosch anti-lock braking system8	●	●	●	●	●	○	
SC718	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
SC718	ABS	Bosch anti-lock braking system9(K Line)	●	●	●	●	●	○	0x6B 0x25
SC718	SRS	Jinheng 4AB Airbags	●	●	●	●	○	○	
SC718	SRS	AUTOLIV Airbags	●	●	●	●	○	○	0x6B
SC718	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SC718	Body Control System	Shanghai Hu gong body control system	●	●	●	●	●	○	0x89 0x57
SC718	Body Control System	Shanghai Hu gong body control system	●	●	●	●	●	○	0x89 0x57
SX718	Engine System	Delphi MT22.1 engine system(K Line)	●	●	●	●	●	●	0x4C 0x40
SX718	Engine System	Delphi MT22.1 engine system(CAN)	●	●	●	●	●	○	0x4C 0x40
SX718	SRS	Bosch ACU system	●	●	●	●	●	○	0x10 0x6B 0x5B
SX718	SRS	TAKATA airbag system (KEPF)	●	●	●	●	○	○	0x4C
SX718	Body Control System	Lear Body Control System(K Line)	●	●	●	●	●	○	0x6B 0x57
SX718	Body Control System	Continental Body Control System	●	●	●	●	●	○	0x84 0x85 0x86
SX718	ABS	Bosch anti-lock braking system8(K Line)	●	●	●	●	●	●	0x25 0x50
SX718	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
SX718	Instrument Panel System	Continental instrument system	●	●	●	●	●	○	0x6C 0x6D
SX718	BMCS	Tire Pressure Monitoring and Security Control (BMCS) System	●	●	○	●	○	○	0x37
SX718	ESP	Bosch ESP9	●	●	●	●	○	○	0x10 0x6B 0x70 0x77 0x6A
SX718	Electronic Parking Lock System	Marquardt electronic parking lock system	●	●	●	○	○	○	
SX718	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SX718	TPMS	Wisdom Electronics Equipment System	●	●	○	●	○	○	0x36
SX718	TPMS	DIAS tire pressure monitoring systems	●	●	●	●	○	○	0x7D
SX718	Keyless Start System	Hella keyless start system	●	●	●	●	●	○	
SX720	Engine System	Delphi MT22.1 engine system(K Line)	●	●	●	●	●	●	0x4C 0x40
SX720	Engine System	Delphi MT22.1 engine system(CAN)	●	●	●	●	●	○	0x4C 0x40
SX720	Automatic Transmission System	DSI 6AT	●	●	●	●	○	○	
SX720	SRS	TAKATA airbag system	●	●	●	●	○	○	0x5B
SX720	SRS	Bosch ACU system	●	●	●	●	●	○	0x10 0x6B 0x5B
SX720	Body Control System	Continental Body Control System (BCM Diagnosis)	●	●	●	●	●	○	0x87
SX720	ABS	Bosch anti-lock braking system8	●	●	●	●	●	○	0x5C 0x5E 0x6F
SX720	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
SX720	Instrument Panel System	Deco combination instrument system	●	●	●	○	●	○	
SX720	Instrument Panel System	Continental instrument system	●	●	●	●	●	○	0x6C 0x6D
SX720	ESP	Bosch ESP9	●	●	●	●	○	○	0x10 0x6B 0x70 0x77 0x6A

Model	System	System Type	Read Codes	Erase Codes	Ecu Info.	Live Data	Active Test	Freeze Frame	Special Function
SX720	Electronic Parking Lock System	Marquardt electronic parking lock system	●	●	●	○	○	○	
SX720	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SX720	TPMS	Wisdom Electronics Equipment System	●	●	○	●	○	○	0x36
SX720	TPMS	DIAS tire pressure monitoring systems	●	●	●	●	○	○	0x7D
SX720	Keyless Start System	Hella keyless start system	●	●	●	●	●	○	
SX725	Engine System	Delphi MT22.1 engine system(K Line)	●	●	●	●	●	●	0x4C 0x40
SX725	Engine System	Delphi MT22.1 engine system(CAN)	●	●	●	●	●	○	0x4C 0x40
SX725	Automatic Transmission System	DSI 6AT	●	●	●	●	○	○	
SX725	SRS	TAKATA airbag system	●	●	●	●	○	○	0x5B
SX725	SRS	Bosch ACU system	●	●	●	●	●	○	0x10 0x6B 0x5B
SX725	Body Control System	Continental Body Control System (BCM Diagnosis)	●	●	●	●	●	○	0x87
SX725	ABS	Bosch anti-lock braking system8	●	●	●	●	●	○	0x5C 0x5E 0x6F
SX725	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
SX725	Instrument Panel System	Deco combination instrument system	●	●	●	○	●	○	
SX725	Instrument Panel System	Continental instrument system	●	●	●	●	●	○	0x6C 0x6D
SX725	ESP	Bosch ESP9	●	●	●	●	○	○	0x10 0x6B 0x70 0x77 0x6A
SX725	Electronic Parking Lock System	Marquardt electronic parking lock system	●	●	●	○	○	○	
SX725	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
SX725	TPMS	Wisdom Electronics Equipment System	●	●	○	●	○	○	0x36
SX725	TPMS	DIAS tire pressure monitoring systems	●	●	●	●	○	○	0x7D
SX725	Keyless Start System	Hella keyless start system	●	●	●	●	●	○	
TX4 2.4 Litre gasoline	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
TX4 2.4 Litre gasoline	Engine System	4G69 Engine Delphi MT80 System	●	●	●	●	●	●	0x4C 0x40
TX4 2.4 Litre gasoline	Engine System	Delphi MT80 Engine System	●	●	●	●	●	○	0x4C 0x40
TX4 2.4 Litre gasoline	Engine System	Bosch EDC16	●	●	●	●	●	○	0x27 0x28 0x29
TX4 2.4 Litre gasoline	Automatic Transmission System	DSI 6AT	●	●	●	●	○	○	
TX4 2.4 Litre gasoline	ABS	Delphi 7.4 ABS	●	●	●	●	●	○	0x66 0x67
TX4 2.4 Litre gasoline	ABS	Delphi 7.4 ABS(K Line)	●	●	●	●	●	○	0x18
TX4 2.4 Litre gasoline	SRS	TAKATA airbag system	●	●	●	●	○	○	0x5B
TX4 2.4 Litre gasoline	Immobilizer System	Jicheng Immobilizer System (with Delphi	●	●	●	●	○	○	
TX4 2.5 Litre diesel	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
TX4 2.5 Litre diesel	Engine System	4G69 Engine Delphi MT80 System	●	●	●	●	●	●	0x4C 0x40
TX4 2.5 Litre diesel	Engine System	Delphi MT80 Engine System	●	●	●	●	●	○	0x4C 0x40
TX4 2.5 Litre diesel	Engine System	Bosch EDC16	●	●	●	●	●	○	0x27 0x28 0x29
TX4 2.5 Litre diesel	Automatic Transmission System	DSI 6AT	●	●	●	●	○	○	
TX4 2.5 Litre diesel	ABS	Delphi 7.4 ABS	●	●	●	●	●	○	0x66 0x67

Model	System	System Type	Read Codes	Erase Codes	Ecu Info.	Live Data	Active Test	Freeze Frame	Special Function
TX4 2.5 Litre diesel	ABS	Delphi 7.4 ABS(K Line)	●	●	●	●	●	○	0x18
TX4 2.5 Litre diesel	SRS	TAKATA airbag system	●	●	●	●	○	○	0x5B
TX4 2.5 Litre diesel	Immobilizer System	Jicheng Immobilizer System (with Delphi	●	●	●	●	○	○	
Haijing	Engine System	Union Electron Engine System	●	●	●	●	●	○	0x4C
Haijing	Engine System	Methanol Engine	●	●	●	●	●	○	
Haijing	ABS	Bosch 8.0 anti-lock braking system	●	●	●	●	●	○	0x18 0x0B
Haijing	ABS	SABS MK70 ABS System	●	●	●	●	○	○	0x4E 0x15 0x16
Haijing	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
Haijing	SRS	Jinheng 4AB Airbags	●	●	●	●	○	○	
Haijing	Body Control System	Shanghai Hu gong body control system	●	●	●	●	●	○	0x89 0x57
Haijing	Immobilizer System	Immobilizer System (with UAES EMS)	●	●	●	●	○	○	
KingKong	Engine System	479QN Engine UAES M7.8 System	●	●	●	●	●	○	0x4C
KingKong	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
KingKong	Engine System	M797 Engine System	●	●	●	●	●	○	
KingKong	Engine System	Delphi MT80 Engine System	●	●	●	●	●	●	0x4C 0x40
KingKong	Engine System	Delphi MT22U CNG system	●	●	●	●	●	●	0x4D 0x0B
KingKong	ABS	SABS MK60 Anti-Lock Braking System	●	●	●	●	○	○	0x4E 0x15 0x16
KingKong	ABS	Bosch 8.0 anti-lock braking system	●	●	●	●	●	○	0x18 0x0B
KingKong	ABS	SABS MK70 ABS System	●	●	●	●	○	○	0x4E 0x15 0x16
KingKong	SRS	Bosch AB8.0 Airbag	●	●	●	●	●	○	
KingKong	SRS	BOSCH AB10 Airbags	●	●	○	●	●	○	0x6B
KingKong	SRS	Yanfeng KSS Airbag	●	●	○	●	●	○	0x6B
KingKong	SRS	Bosch ACU system	●	●	●	●	●	○	0x10 0x6B 0x5B
Golden Eagle	Engine System	UAES EOBD Engine System	●	●	●	●	●	○	0x4C
Golden Eagle	Engine System	Delphi MT20U2 Engine System	●	●	●	●	●	●	0x4C 0x0B
Golden Eagle	ABS	SABS MK60 Anti-Lock Braking System	●	●	●	●	○	○	0x4E 0x15 0x16
Golden Eagle	ABS	Bosch 8.0 anti-lock braking system	●	●	●	●	●	○	0x18 0x0B
Golden Eagle	ABS	SABS MK70 ABS System	●	●	●	●	○	○	0x4E 0x15 0x16
Golden Eagle	SRS	Bosch AB8.0 Airbag	●	●	●	●	●	○	
Golden Eagle	SRS	BOSCH AB10 Airbags	●	●	○	●	●	○	0x6B
Golden Eagle	SRS	Yanfeng KSS Airbag	●	●	○	●	●	○	0x6B
Golden Eagle	SRS	Bosch ACU system	●	●	●	●	●	○	0x10 0x6B 0x5B
New KingKong CROSS	Engine System	Continental engine system	●	●	●	●	●	○	0x4C
New KingKong CROSS	Automatic Transmission System	JACTO Automatic Transmission System (CAN)	●	●	●	●	○	○	0x62
New KingKong CROSS	ABS	Continental MK70 anti-lock braking system	●	●	●	●	●	○	0x63 0x15
New KingKong CROSS	ABS	Continental MK70 anti-lock braking system(K Line)	●	●	●	●	○	○	0x4E 0x15 0x16

Model	System	System Type	Read Codes	Erase Codes	Ecu Info.	Live Data	Active Test	Freeze Frame	Special Function
New KingKong CROSS	SRS	BOSCH AB10 Airbags	●	●	○	●	●	○	0x6B
New KingKong CROSS	SRS	TRW airbag system	●	●	●	●	○	○	0x64
New KingKong CROSS	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
New KingKong CROSS	Instrument Panel System	Deco combination instrument system	●	●	●	○	●	○	0x70
New KingKong CROSS	Power Steering System	JTEKT EPS system	●	●	○	●	○	○	
New KingKong hatchback	Engine System	Continental engine system	●	●	●	●	●	○	0x4C
New KingKong hatchback	Automatic Transmission System	JACTO Automatic Transmission System (CAN)	●	●	●	●	○	○	0x62
New KingKong hatchback	ABS	Bosch anti-lock braking system8	●	●	●	●	●	○	
New KingKong hatchback	ABS	Bosch anti-lock braking system9	●	●	●	●	●	○	0x6B 0x6F 0x51 0x52
New KingKong hatchback	ABS	Bosch anti-lock braking system8(K Line)	●	●	●	●	●	○	0x50 0x25
New KingKong hatchback	SRS	BOSCH AB10 Airbags	●	●	○	●	●	○	0x6B
New KingKong hatchback	SRS	Continental Airbag System	●	●	●	●	●	○	0x4C 0x5D
New KingKong hatchback	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
New KingKong hatchback	Instrument Panel System	Deco combination instrument system	●	●	●	○	●	○	0x70
New KingKong hatchback	Power Steering System	JTEKT EPS system	●	●	○	●	○	○	
New KingKong seden	Engine System	Continental engine system	●	●	●	●	●	○	0x4C
New KingKong seden	Automatic Transmission System	JACTO Automatic Transmission System (CAN)	●	●	●	●	○	○	0x62
New KingKong seden	ABS	Continental MK70 anti-lock braking system	●	●	●	●	●	○	0x63 0x15
New KingKong seden	ABS	Continental MK70 anti-lock braking system(K Line)	●	●	●	●	○	○	0x4E 0x15 0x16
New KingKong seden	SRS	BOSCH AB10 Airbags	●	●	○	●	●	○	0x6B
New KingKong seden	SRS	TRW airbag system	●	●	●	●	○	○	0x64
New KingKong seden	Immobilizer System	Shanghai Industrial Theft-deterrent System	●	●	●	●	○	○	
New KingKong seden	Instrument Panel System	Deco combination instrument system	●	●	●	○	●	○	0x70
New KingKong seden	Power Steering System	JTEKT EPS system	●	●	○	●	○	○	

Special_Function

index	Special Function Name	index	Special Function Name
0x01	Version Information	0x02	Read DTCs
0x03	Freeze Frame	0x04	Clear DTCs
0x05	DataStream	0x06	Active Test
0x07	Parameter Adjustment	0x08	Program
0x09	Special Function	0x0A	O2 Sensor Monitoring
0x0B	End-of-Line Test	0x0C	Remote Control Matching
0x0D	Service Lamp Reset	0x0E	Input Code
0x0F	Immobilizer Matching	0x10	ECU Reset
0x11	Warning Light Configuration	0x12	Steering Angle Sensor Calibration
0x13	Restore Default	0x14	Automatic Bleeding
0x15	Hydraulic Control Unit Test	0x16	Bleeding and Filling
0x17	EOBD Module	0x18	Bleeding Mode
0x19	Write Data	0x1A	Matching Function
0x1B	Reset Adaptive Value	0x1C	Vehicle Service
0x1D	Coding	0x1E	Activate Alarm Horn
0x1F	CAN Configuration Selection	0x20	CAN Configuration Input
0x21	Initialize Tire Location	0x22	ISU Reset
0x23	Fast Dormancy	0x24	Shipping Mode
0x25	Air Bleeding Function	0x26	O2 Sensor Test
0x27	Engine Test	0x28	Fuel Injector Matching
0x29	Read Fuel Injector Code	0x2A	2-Airbag Automatch
0x2B	6-Airbag Automatch	0x2C	End-of-Line Function
0x2D	Brake Bleeding	0x2E	Check Program Control Service
0x2F	Service Light	0x30	Customized List
0x31	Coding	0x32	Basic Settings
0x33	Security Access	0x34	Separate Reading
0x35	System Operation	0x36	Sensor Learn
0x37	Learn Function	0x38	Key Learn
0x39	Weaving angle speed sensor calibration	0x3A	Configuration Function
0x3B	AT And ABS/ESP Configuration	0x3C	Run-In
0x3D	ECU Reset	0x3E	ECU Configuration
0x3F	Open/Close Knock Output Command	0x40	Gear deviation learning
0x41	ICU Configuration	0x42	Vacuumpumping And Filling
0x43	Change Hydraulic pressure module refuel	0x44	Change EOL Detection Status
0x45	Change Variable Code	0x46	Manual Exhaust
0x47	Filling And drainage(3 channel)	0x48	Filling And drainage(4 channel)
0x49	EMS Collocate ACU	0x4A	match Set
0x4B	ABS Test	0x4C	Write VIN Code
0x4D	Write Data	0x4E	ECU coding
0x4F	Reset Self-Learning Value	0x50	Set Variable Code
0x51	Speed Limit	0x52	Valve Relay Off
0x53	Diagnostic Instruction	0x54	Cornering Lamp Fault Counter
0x55	Function Setting	0x56	Control LED Light Test
0x57	Remote Control Learning	0x58	Learn Keys
0x59	Configuration Setting	0x5A	Delete Sensor Information
0x5B	Off Line Matching Function	0x5C	Write Filling Status
0x5D	Ignition Function Setting	0x5E	Write EOL Test Status
0x5F	Locking All Ignition Circuits	0x60	Unlock All Ignition Circuits
0x61	Off Line Configuration Function	0x62	Clear learning code
0x63	Vehicle Configuration	0x64	EOL Function
0x65	Write Configuration Function	0x66	Exhausting and Filling 1
0x67	Exhausting and Filling 2	0x68	Erase EMS
0x69	Learn EMS	0x6A	Sensor Calibration
0x6B	Write Data Function	0x6C	Write vehicle configuration
0x6D	Write instrument panel configuration	0x6E	Steering Angle Calibration
0x6F	Service Bleeding	0x70	Write configuration information
0x71	Write network node configuration	0x72	Write function configuration

index	Special Function Name	index	Special Function Name
0x73	Write AC function configuration code	0x74	Restore factory settings
0x75	Reset underdrive emergency braking counter	0x76	ECU function configuration
0x77	Cornering angle calibration	0x78	Release lining
0x79	Seat calibration	0x7A	Steering wheel adjustment calibration
0x7B	Rear view mirror test	0x7C	Head up display reset
0x7D	Reset service mileage	0x7E	Sensor matching
0x7F	Write vehicle information data	0x80	Static side view assist test
0x81	LED warning light test	0x82	Button LED test
0x83	CIU configuration	0x84	Write vehicle model information
0x85	Write body controller information	0x86	Configure rain sensor sensitivity
0x87	Learn Remote Key	0x88	Read product mode
0x89	Delete remote control		