

## MaxiSys\_Great Wall\_V3. 70 Function List (Note:For reference only)

## Note:

- indicates the function is supported. \*\* indicates the function may be supported according to actual vehicle conditions.
- O indicates the function is not available. indicates the function is newly added to the latest version.

Refer to the Special Function List for details.

Refer to the	Special Function List for deta	ils.							
Model	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Haval H3	Engine	Delphi MT20U2 EOBD engine system		•	•	•	•	•	0012 0015
Haval H3	Engine	BOSCH V50 Diesel Engine System		•	•	•	•	•	0011
Haval H3	Engine	BOSCH-EDC16 Diesel Engine System	•	•	0	•	•	0	0001 0002 0003 0004 0005 0006 0027
Haval H3	Engine	Delphi System(MT20U)	•	•	0	•	•	0	
Haval H3	Engine	Liaoning Xinfeng Electronic Control	•	•	•	•	•	•	0021 0011 0015
Haval H3	Antilock Brake System	BOSCH ABS System	•	•	•	•	•	0	0013
Haval H3	VECU System	Delphi Body Control System	•	•	•	•	•	0	0030 0018 0019
Haval H3	VECU System	Tongzhi body control system	•	•	•	•	•	0	0030 0029 007A
Haval H3	SRS System	Jinzhou Jinheng Airbags	•	•	•	•	0	0	
Haval H3	SRS System	BOSCH Airbags	•	•	•	•	0	0	
Haval H3	SRS System	Mainland Airbag System	•	•	•	0	•	0	
Haval H3	SRS System	TRW airbag	•	•	•	•	0	0	0030
Haval H3	Immobilizer System	Delphi gasoline anti-theft system	•	•	•	•	0	0	0025
Haval H3	Immobilizer System	Delphi diesel (Bosch 2.8TC) anti- theft system	•	•	•	•	0	0	0025
Haval H3	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078
GWPeri, Haval M1	Engine	GW413EF UAES EOBD Engine System	•	•	•	•	•	0	0012
GWPeri, Haval M1	Engine	UAES M797 System	•	•	•	•	•	•	
GWPeri, Haval M1	Antilock Brake System	BOSCH ABS System		•	•	•	•	0	0013
GWPeri, Haval M1	Antilock Brake System	Great Wall Jingling ABS System				•	•	0	0013
GWPeri, Haval M1	SRS System	Jinzhou Jinheng Airbags	•	•		•	0	0	
GWPeri,Haval M1	Immobilizer System	Shanghai Industrial Communication Theft-deterrent System	•	•	•	•	0	0	0025
GWPeri,Haval M1	Immobilizer System	Great Wall Jingling Theft-deterrent System	•	•	•	•	•	0	0014
Cowry, Great Wall	Engine	Delphi System(MT20U2)	•	•	•	•	•	0	
Cowry, Great Wall	Engine	Delphi MT80 Engine System	•	•	•	•	•	•	0015 0051
Cowry, Great Wall	Engine	UAES 1.5 T engine system	•	•	•	•	•	•	
Cowry, Great Wall	AT System	Hyundai Mobis P4MFI AT System	•	•		•	•	0	
Cowry, Great Wall	Antilock Brake System	BOSCH ABS System	•	•		•	•	0	0013
Cowry, Great Wall	Antilock Brake System	Bosch ABS8 system (K)		•	•	•	•	•	0056 0057
Cowry, Great Wall	SRS System	Jinzhou Jinheng Airbags		•	•	•	0	0	
Cowry, Great Wall	SRS System	Great Wall Jingling, COWRY SRS	•	•	•	•	0	0	
Cowry, Great Wall	Immobilizer System	Delphi gasoline anti-theft system	•	•	•	•	0	0	0025
Wingle	Engine	Delphi System(MT20U2)		•	•	•	•	0	
Wingle	Engine	BOSCH V50 Diesel Engine System	•	•	•	•	•	•	0011

Model	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Wingle	Engine	Liaoning Xinfeng Electronic Control System	•	•	•	•	•	•	0021 0011 0015
Wingle	Engine	UMC Euro4 System	•	•	•	•	•	•	
Wingle	Engine	4D20 Delphi Electronic Control System	•	•	•	•	•	0	0030 0029 0027 0071 0015
Wingle	Engine	4D20 Bosch diesel engine system	•	•	•	•	•	0	0030 0029 0027
Wingle	Engine	Delphi 4D20 EU 5 engine system	•		•	•	•	0	0030 0029
Wingle	Antilock Brake System	BOSCH ABS System	•		•	•		0	0013
Wingle	Antilock Brake System	Bosch ABS (CAN)			•	•	•	0	0030 0056 0079
Wingle	SRS System	Jinzhou Jinheng Airbags	•		•	•	0	0	
Wingle	Immobilizer System	Delphi gasoline anti-theft system	•		•	•	0	0	0025
Wingle	Immobilizer System	Delphi diesel (Bosch 2.8TC) anti- theft system	•	•	•	•	0	0	0025
Wingle	Immobilizer System	Delphi diesel (Delphi 4D20) anti- theft system	•	•	•	•	0	0	0025
Wingle	Immobilizer System	Delphi diesel (Bosch 4D20) anti- theft system	•	•	•	•	0	0	0025
Wingle	Immobilizer System	Delphi gasoline (UMC) anti-theft	•	•	•	•	0	0	0025
Wingle	Immobilizer System	Delphi Bosch (EDC17C63) anti-theft system	•	•	•	•	0	0	0025
Florid, M4	Engine	UAES M797 System	•	•	•	•	•	•	
Florid, M4	Engine	Delphi EOBD ECU	•	•	•	•	•	•	
Florid, M4	Engine	Siemens Engine System	•	•	•	•	•	•	
Florid, M4	AT System	Punch VT2 CVT system	•	•	•	•	0	0	007B
Florid, M4	AT System		•	•	•	•	0	•	0050
Florid, M4	Antilock Brake System	BOSCH ABS System	•	•	•	•	•	0	0013
Florid, M4	Antilock Brake System	Great Wall Jingling ABS System			•	•	•	0	0013
Florid, M4	Antilock Brake System	TRW ABS			•	•	•	0	0013
Florid, M4	SRS System	AUTOLIV Airbags			•	•	•	0	
Florid, M4	SRS System	CHO41 Autoliv Airbag	•		•	•	0	0	
Florid, M4	Immobilizer System	Shanghai Industrial Communication Theft-deterrent System	•	•	•	•	0	0	0025
Cool Bear, Haval M2	Engine	UAES II Electronic Control Unit	•	•	•	•	•	•	
Cool Bear, Haval M2	Engine	UAES M797 System	•	•	•	•	•	•	
Cool Bear, Haval M2		Punch VT2 CVT system	•	•	•	•	0	0	007B
Cool Bear, Haval M2		Automatic transmission system (AMT)		•	•	•	0	•	0050
Cool Bear, Haval M2	Antilock Brake System	Great Wall Jingling ABS System			•	•	•	0	0013
Cool Bear, Haval M2	Antilock Brake System	TRW ABS			•	•	•	0	0013
Cool Bear, Haval M2	SRS System	AUTOLIV Airbags	•		•	•		0	
Cool Bear, Haval M2	SRS System	Jinzhou Jinheng Airbags	•	•	•	•	0	0	
Cool Bear, Haval M2	Immobilizer System	Lianchuang Anti-theft System(4G93 Or 4G15 Engine)	•	•	•	•	•	0	0025
Lingao,Great Wall C20R	Engine	UAES M797 System	•	•	•	•	•	•	
Lingao, Great Wall C20R	Engine	Siemens Engine System	•	•	•	•	•	•	

Lingao, Great Wall C20R  Lingao, Great Wall C20R  AT System  AT System  AUtomatic transmission system (AMT)  AT System  AUtomatic transmission system (AMT)  AT System  O 0015 0030  O 07B	
C20R   All System   Punch_VI2_CVI system   O 007B   Lingao, Great Wall   All System   Automatic transmission system (AMT)   O 0050	
All Syctom Alltomatic transmission systom (AMI) I I I I I I I I I I I I I I I I I I	
C20R Automatic transmission system (AMT)	
Lingao, Great Wall C2OR Antilock Brake System BOSCH ABS System   BOSCH ABS System   O 0013	
Lingao, Great Wall C20R Antilock Brake System TRW ABS	
Lingao, Great Wall C2OR Antilock Brake System Bosch ESP system    Bosch ESP system    O 0040 0056	0029 007C 0030
Lingao, Great Wall C2OR  Antilock Brake System  Bosch ABS9 system (K)	
Lingao, Great Wall C2OR SRS System AUTOLIV Airbags	
Lingao, Great Wall C20R CH041 Autoliv Airbag    CH041 Autoliv Airbag    CH041 Autoliv Airbag	
Lingao, Great Wall Power Steering System Yubei EPS Steering System • O O O	
Lingao, Great Wall Communication COMMUNICATION Theft-deterrent System  Shanghai Industrial Communication Theft-deterrent System	
Great Wall C30 Engine UAES M797 System ● ● ● ● ●	
Great Wall C30 Engine Siemens Engine System	
Great Wall C30   Engine   UMC Start / Stop Engine System   ●   ●   ●   ●   ●   0082 0031 0035 0032	0034 0033 0036
Great Wall C30 Engine UAES engine (CAN)	
Great Wall C30 Engine UMC engine (new version)	
Great Wall C30 AT System Punch VT2 CVT system ● ● ● O O 007B	
Great Wall C30 AT System Automatic transmission system (AMT) ● ● ● ○ ○ ● 0050	
Great Wall C30 AT System GETRAG AMT (UMC) ● ● ● ● O 0015 0073	0072
Great Wall C30 Antilock Brake System BOSCH ABS System ● ● ● ● O 0013	
Great Wall C30 Antilock Brake System Great Wall Jingling ABS System ● ● ● ● ○ ○ 0013	
Great Wall C30 Antilock Brake System TRW ABS ● ● ● ● O 0013	
Great Wall C30 Antilock Brake System Bosch ABS8 system (K) ● ● ● ● 0056 0057	
Great Wall C30 Antilock Brake System Bosch ABS (ESP) system (CAN) ● ● ● ● O 0056 0079	0030 0029
Great Wall C30 SRS System AUTOLIV Airbags ● ● ● ● O	
Great Wall C30 SRS System CH041 Autoliv Airbag ● ● ● O O	
Great Wall C30 Immobilizer System Shanghai Industrial Communication Theft-deterrent System	
Great Wall C30 Instrument Panel System Delco ● ● ○ ○ ○ ○ 0076 0030	0077
Great Wall C30 Instrument Panel System STEC ● ● ● ● O 0030 0077	
Great Wall C30 Remote Controller Matching System Remote control system O O O O O 0	
Great Wall C30 Keyless Start System Kstar push-start PEPS system • • • • O 0030 0068	
Haval H5 Engine BOSCH V50 Diesel Engine System • • • • • 0011	
Haval H5 Engine Delphi MT20U2 EOBD engine system ● ● ● ● 0012 0015	

Model	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Fun	ction		
Haval H5	Engine	4D20 Delphi Electronic Control System	•	•	•	•	•	0	0030 0029	0027	0071	0015
Haval H5	Engine	4D20 Bosch diesel engine system	•	•	•	•	•	0	0030 0029	0027		
Haval H5	Engine	Delphi System(MT20U)	•	•	0	•	•	0				
Haval H5	Engine	4G63T engine system	•	•	•	•	•	0	0015 0051			
Haval H5	AT System	Hyundai Mobis 5R35 AT System	•	•	•	•	•	0				
Haval H5	Antilock Brake System	BOSCH ABS System	•	•	•	•	•	0	0013			
Haval H5	Antilock Brake System	Bosch ABS (CAN)	•	•	•	•	•	0	0056 0074	0079	0030	
Haval H5	Antilock Brake System	Bosch ABS9 ESP system	•	•	•	•	•	0	0056 0079		0029	
	VECU System	Delphi Body Control System	•	•	•	•	•	0		0019	0020	
	VECU System	Tongzhi body control system	•	•	•	•	•	0		007A		
Haval H5	VECU System	Delphi body control system (CAN)	•	•	•	•	•	0		0019		
	VECC System	Continent Instrument System (CAN	<del>                                     </del>					0		0013		
Haval H5	Instrument Panel System	Network)		•	•	•	•	0	0030 0029			
Haval H5	SRS System	BOSCH Airbags	•	•	•	•	0	0				
Haval H5	SRS System	TRW airbag	•	•	•	•	0	0	0030			
Haval H5	SRS System	Mainland Airbag System	•	•	•	0	•	0	0000			
Haval H5	SRS System	Bosch airbag system (CAN)	•	•	•	0	0	0	0030 0029			
Haval H5	Immobilizer System	Delphi gasoline anti-theft system	•	•	•		0	0	0025			
	ü.	Delphi diesel (Bosch 2.8TC) anti-										
Haval H5	Immobilizer System	theft system	•	•	•	•	0	0	0025			
Haval H5	Immobilizer System	Delphi diesel (Delphi 4D20) anti- theft system	•	•	•	•	0	0	0025			
Haval H5	Immobilizer System	Delphi diesel (Bosch 4D20) anti- theft system	•	•	•	•	0	0	0025			
Haval H5	TOD System	Borgwarner TOD System(Intelligent 4WD)	•	•	•	•	•	0	0030			
Haval H5	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078			
Pickup and early models (Sailing, Di'er, Saic	Engine	Delphi ECU System	•	•	•	•	•	0				
(Sailing, Di er, Saic ool, Saiiun, Saiving)	Engine	Union	•	•	•	•	0	0	007Е			
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	UAES II Electronic Control Unit	•	•	•	•	•	•				
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	Aerospace Mitsubishi Electronic Control System	•	•	•	•	•	0				

Model	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	MARELLI Single Point System	•	•	0	•	•	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	BOSCH-EDC16 Diesel Engine System	•	•	0	•	•	0	0001 0002 0003 0004 0005 0006 0027
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	Delphi EOBD ECU	•	•	•	•	•	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Engine	4L88 Engine EGR System	•	0	0	•	0	0	0010 0079
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Engine	BOSCH V50 Diesel Engine System	•	•	•	•	•	•	0011
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Engine	GW413EF UAES EOBD Engine System	•	•	•	•	•	0	0012
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	Delphi MT80 Engine System	•	•	•	•	•	•	0015 0051
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	Delphi System(MT20U)	•	•	0	•	•	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	UAES M797 System	•	•	•	•	•	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	Delphi System(MT20U2)	•	•	•	•	•	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine	UMC Euro4 System	•	•	•	•	•	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)		Greatwall AT System	•	•	0	•	0	0	

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	AT System	Siemens Transmission	•	•	•	•	•	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Antilock Brake System	BOSCH ABS System	•	•	•	•	•	0	0013
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Antilock Brake System	Great Wall Jingling ABS System	•	•	•	•	•	0	0013
(Salling, Di er, Saic ool, Sai iun, Saiving)	SRS System	Great Wall Hover SRS	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	SRS System	Great Wall Wingle SRS	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	SRS System	Great Wall Jingling,COWRY SRS	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	SRS System	BOSCH Airbags	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	SRS System	AUTOLIV Airbags	•	•	•	•	•	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Immobilizer System	Delphi gasoline anti-theft system	•	•	•	•	Ο	0	0025
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Immobilizer System	Great Wall Jingling Theft-deterrent System	•	•	•	•	•	0	0014
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Immobilizer System	Delphi diesel (Bosch 2.8TC) anti- theft system	•	•	•	•	0	0	0025
Haval H8	Engine	Engine electronic control system (ECM)	•	•	•	•	•	0	0051 0015 0030
Haval H8	AT System	Transmission electronic control system (TCU)	•	•	•	•	0	0	0060 0030

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Haval H8	Electronic stability program (ESP)	Electronic stability program (ESP)	•	•	•	•	0	0	0030 0056
Haval H8	VECU System	Body control system (BCM)	•	lacktriangle	lacktriangle	•	•	0	0030 0059 0055
Haval H8	Instrument Panel System	Instrument panel system (IP)	•	lacktriangle	lacktriangle	0	•	0	0062 0063 0030 0077
Haval H8	SRS System	Airbag (ABM)	•			•	0		0030 0058
Haval H8	Automatic Air-conditioning System	A/C control system (AC)	•	•	•	•	0	0	0030
Haval H8	Keyless Start System	Kstar push-start PEPS system	•	•	•	•	•	0	0030 0068
Haval H8	Torque on demand (TOD)	Torque on demand (TOD)	•	•	•	•	•	0	0030
Haval H8	Steering Wheel Angle Sensor	Steering wheel angle sensor (SAS)	•	•	•	•	0	0	0030 0079
Haval H8	Adaptive front lighting system (AFS)	Adaptive front lighting system (AFS)	•	•	•	•	•	0	0064 0030
Haval H8	Gateway (GW)	Gateway (GW)	•	•	•	0	0	0	0030
Haval H8	Driver side door system (DDCM)	Driver side door system (DDCM)	•	•	•	0	0	0	0030
Haval H8	Front passenger side door system (PDCM)	Front passenger side door system (PDCM)	•	•	•	0	0	0	0030
Haval H8	Driver side seat memory system (DSM)	Driver side seat memory system (DSM)	•	•	•	0	•	0	0030
Haval H8	Rain light sensor (RLS)	Rain light sensor (RLS)	0	0	0	0	0	0	0065
Haval H8	Parking assistant system (Front)	Parking assistant system (Front)	0	0	•	0	0	0	0069 0070
Haval H8	Parking assistant system	Parking assistant system (Rear)	0	0	•	0	0	0	0080 0081
Haval H8	Rear view camera (RVC)	Rear view camera (RVC)	0	0	•	0	0	0	0030
Haval H8	Entertainment system (CD)	Entertainment system (CD)	•	•	•	0	0	0	0030
Wingle6	Engine	4D20 Bosch diesel engine system	•	•	•	•	•	0	0030 0029 0027
Wingle6	Engine	Delphi MT80 Engine System	•	•	•	•	•	•	0015 0051
Wingle6	Engine	Delphi 4D20 EU 5 engine system	•	•	•	•	•	0	0030 0029 0027 0071
Wingle6	Antilock Brake System	Anti-Lock brake system (ABS)	•	•	•	•	•	0	0030 0056 0079
Wingle6	VECU System	Body control system (BCM)		•	•	•	•	0	0030 0019 0055
Wingle6	Instrument Panel System	Instrument panel system (IP)		•	•	0	•	0	0030
Wingle6	SRS System	Supplemental restraint system (ABM)	•			•	•	0	0030
Wingle6	Automatic Air-conditioning System	A/C control system (AC)	•	•	•	•	0	0	0030
Wingle6	Borgwarner TOD System(Intelligent 4WD)	Borgwarner TOD System(Intelligent 4WD)	•	•	•	•	0	0	0030
Wingle6	Immobilizer System	Delphi diesel (Delphi 4D20) anti- theft system	•	•	•	•	0	0	0025
Wingle6	Immobilizer System	Delphi diesel (Bosch 4D20) anti- theft system	•	•	•	•	0	0	0025
Wingle6	Immobilizer System	Delphi gasoline anti-theft system	•	•	•	•	0	0	0025
Wingle6	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078
Great Wall C50-2013		Engine	•	•	•	•	•	0	0030
	Antilock Brake System	Antilock Brake System	•	•	•	•	0	0	0056 0030
Great Wall C50-2013	Electronic stability program (ESP)		•	•		•	0	0	0056 0079 0030
Great Wall C50-2013		Delphi body controller system	•	•	•	•	•	0	0019 0055 0030
	Instrument Panel System	IP system	•	•		0	0	0	007D 0030 0077

			Varation	Dand	Clear	Read	Read Freeze	A - + i	
Mode1	System	ECU	Version Info.	Read DTCs	DTCs	Read DataStream	Frame	Test	Special Function
Great Wall C50-2013		SRS System	•	•	•	0	0	0	0030
Great Wall C50-2013	Automatic Air-conditioning System	A/C control system (AC)	•	•	•	0	•	0	0030
	Keyless Start System	Kstar knob PEPS system		•	•	•	•		0029 0030 0068
Great Wall C50-2013		Parking assistant system (PAS)	•	•	•	0	0	0	0030
Great Wall C50-2013	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078
Great Wall C50- Sport(JZ40)	Engine	Engine	•	•	•	•	•	0	0030
Great Wall C50- Sport(JZ40)	Antilock Brake System	Antilock Brake System	•	•	•	•	0	0	0056 0030
Great Wall C50- Sport(JZ40)	Electronic stability program (ESP)	Electronic stability program (ESP)	•	•	•	•	0	0	0056 0079 0030
Great Wall C50- Sport(JZ40)	VECU System	Body controller system	•	•	•	•	•	0	0019 0055 0030
Great Wall C50- Sport(JZ40)	Instrument Panel System	IP system	•	•	•	0	0	0	007D 0030 0077
Great Wall C50- Sport(JZ40)	SRS System	SRS System	•	•	•	0	0	0	0030
Great Wall C50- Sport(JZ40)	Keyless Start System	Kstar push-start PEPS system	•	•	•	•	•	0	0030 0068
Great Wall C50- Sport(JZ40)	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078
Great Wall C50- Upgraded(CHB012)	Engine	Engine	•	•	•	•	•	0	0030
Great Wall C50- Upgraded(CHB012)	Antilock Brake System	Antilock Brake System	•	•	•	•	0	0	0056 0030
Great Wall C50- Upgraded(CHB012)	Electronic stability program (ESP)	Electronic stability program (ESP)	•	•	•	•	0	0	0056 0079 0030
Great Wall C50- Upgraded(CHB012)	VECU System	Body controller system	•	•	•	•	•	0	0019 0055 0030
Great Wall C50- Upgraded(CHB012)	Instrument Panel System	IP system	•	•	•	0	0	0	007D 0030 0077
Great Wall C50- Upgraded(CHB012)	SRS System	SRS System	•	•	•	0	0	0	0030
Great Wall C50- Upgraded(CHB012)	Automatic Air-conditioning System	A/C control system (AC)	•	•	•	0	•	0	0030
Great Wall C50- Upgraded(CHB012)	Keyless Start System	Kstar push-start PEPS system	•	•	•	•	•	0	0030 0068
Great Wall C50-2012	Engine	Engine		•	•	•	•	0	0030
Great Wall C50-2012	AT System	Automatic transmission system (AMT)		•	•	•	0		0050
Great Wall C50-2012		Automatic transmission system (CVT)		•	0	•	•		0030
	Antilock Brake System	BOSCH ABS System		•	•	•	0		0056 0030
Great Wall C50-2012		VECU System		•	•	•	•		0029 0019 0030
	Instrument Panel System	Instrument Control System		•	•	0	0		0030 0077
Great Wall C50-2012	SRS System	SRS System	•	•	•	0	0	0	0030 0029
Great Wall C50-2012	Immobilizer System	Shanghai Industrial Communication Theft-deterrent System	•	•	•	•	0	0	0025

Model S	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Great Wall Cou-2012	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078
Haval H6-2012 E	Engine	4D20 Delphi Electronic Control System	•	•	•	•	•	0	0030 0029 0027 0071 0015
Haval H6-2012 E	Engine	4G15T engine electronic control system	•	•	•	•	•	0	0030 0015
	Engine	4D20 Bosch diesel engine system	•	•	•	•	•	0	0030 0029 0027
	Engine	Delphi 4D20 EU 5 engine system	•	•	•	•	•	0	0030 0029
	Engine	Delphi MT80 Engine System	•	•	•	•	•	•	0015 0051
	Engine	Delphi MT20U2 EOBD engine system	•	•	•	•	•	•	0012 0015
	AT System	Hyundai Mobis P4MFI AT System	•	•	•	•	•	0	0.72 0.00 0.72 0.00
	Antilock Brake System	BOSCH ABS System	•	•	•	•	•	0	0056 0029 007C 0030
	Antilock Brake System	Bosch ABS9 ESP system	•	•	•	•	•	0	0030 0029 0056 0079
	VECU System	Delphi body controller	•	•	•	•	•	0	0030 0019 0055
	VECU System	UAES body controller	•	•	•	•	•	0	0019 0030 0029 0055
	Instrument Panel System	SDE instrument control system	•	•	0	0	•	0	0030 0029 0077
Haval H6-2012 S	SRS System	SRS System	•	•	•	0	0	0	0030 0029
	Immobilizer System	Shanghai Industrial Communication Theft-deterrent System	•	•	•	•	0	0	0025
	Immobilizer System	Xiamen Tongzhi Anti-theft System	•	•	•	•	0	0	0025
		Borgwarner TOD System	•	•	•	•	0	0	0030
THAVAL HO-ZULZ	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078
Haval H6-2013 E	Engine	4G15T engine electronic control system	•	•	•	•	•	0	0030 0015
Haval H6-2013 E	Engine	Delphi 4D20 EU 5 engine system	•	•	•	•	•	0	0030 0029
Haval H6-2013 E	Engine	4D20 Bosch diesel engine system	•	•		•	•	0	0030 0029 0027
Haval H6-2013 E	Engine	Delphi MT80 Engine System	•	•		•	•	•	0015 0051
Haval H6-2013 E	Engine	Delphi MT20U2 EOBD engine system	•	•		•	•	•	0012 0015
Haval H6-2013 A	AT System	Hyundai Mobis P4MFI AT System	•	•		•	•	0	
Haval H6-2013 A	AT System	Transmission system (DSI)		•		•	•	0	007D 0030
Haval H6-2013 A	Antilock Brake System	Bosch ABS9 ESP system	•	•		•	•	0	0030 0029 0056 0079
Haval H6-2013 V	VECU System	Delphi body controller				•	•	0	0030 0019 0055
Haval H6-2013 V	VECU System	UAES body controller		•		•	•	0	0019 0030 0029 0055
Haval H6-2013 I	Instrument Panel System	Yazaki instrument control system		•		0	0	0	0030 0077
Haval H6-2013 I	Instrument Panel System	SDE instrument control system	•	lacktriangle	0	0	•	0	0030 0029 0077
Haval H6-2013 S	SRS System	SRS System	•	•		0	0	0	0030 0029
THAVAL HD-/UL3	Automatic Air-conditioning System	A/C control system (CHB022)	•	•	•	•	•	0	0030
Haval H6-2013 A	Automatic Air-conditioning System	A/C control system (CHB021)	•	•	•	0	•	0	0030
	Keyless Start System	Kstar knob PEPS system	•	•	•	•	•	0	0030 0068
	Borgwarner TOD System	Borgwarner TOD System	•	•	•	•	0	0	0030
	Entertainment system	Foryou CD System	•	•	•	Ô	0	0	0030
	Entertainment system	HASE CD System	•	•	•	•	0	0	
		Headlight leveling system (ALS)	•	•	•	•	•	0	0030 0064
		Parking assistant system (PAS)	•	•	•	0	0	0	0030
	Gateway (GW)	Gateway	•	•	•	0	0	0	0030 007F

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Haval H6-2013	Remote Controller Matching System	Remote control system	0	0	O	O	O		0078
Haval H2	Engine	Engine system (ECM)	•	•	•	•	•	0	0030 0015
Haval H2	Antilock Brake System	Anti-Lock brake system (ABS)		•	•	•	•	0	0030 0056
Haval H2	VECU System	Body control system (BCM)	_	•	•	•	•	0	0030 0055
Haval H2	Power Steering System	Electric steering system		•	•	•	0	0	0030 0079
Haval H2	Keyless Start System	Keyless start system (PEPS)		•	•	•	•	0	0030 0068
Haval H2	SRS System	Supplementary Restraint System(SRS)	•	•	•	•	•	0	0030 0075
Haval H2	Instrument Panel System	Instrument panel system (IP)	•	•	•	•	•	0	0030 0062 0063 0077
Haval H2	Borgwarner TOD System	Borgwarner TOD System	•	•	•	•	•	0	0030
Haval H2	Electronic steering column lock (ESCL)	Electronic steering column lock (ESCL)	•	•	•	0	0	0	0030
Haval H2	Headlight leveling system	Headlight leveling system (ALS)	•	•	•	•	•	0	0030 0064
Haval H2	Gateway (GW)	Gateway (GW)	•	•	•	0	0	0	0030
Haval H2	Rear view camera (RVC)	Rear view camera (RVC)	0	0	•	0	0	0	0030
Haval H2	Automatic Air-conditioning System	A/C control system (AC)	•	•	•	•	•	0	0030
Haval H2	Steering Wheel Angle Sensor	Steering wheel angle sensor (SAS)	•	•	•	•	0	0	0030 0040
Haval H1	Engine	Engine electronic control system (ECM)	•	•	•	•	•	0	0015 0030
Haval H1	Antilock Brake System	Anti-Lock brake system (ABS)	•	•	•	•	•	0	0056 0074 0040 0030
Haval H1	VECU System	Body control system (BCM)	•	•	•	•	•	0	0019 0030 0055
Haval H1	Power Steering System	Electric steering system	•	•	•	0	0	0	0030
Haval H1	Instrument Panel System	Instrument panel system (IP)	•	•	0	0	0	0	0030 0077
Haval H1	Immobilizer System	Shanghai Industrial Communication Theft-deterrent System	•	•	•	•	0	0	0025
Haval H1	Remote Controller Matching System	Remote control system	0	0	0	0	0	0	0078
Haval H6 COUPE	Keyless Start System	Keyless start system (PEPS)	•	•	•	•	•	0	0030 0068
Haval H9	Keyless Start System	Kstar push-start PEPS system	•	•	•	•	•	0	0030 0068



## Specil\_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Compression Test	0002	Fuel Injection Comparison
0003	Idle RPM Comparison	0004	High Speed Test
0005	High Voltage Test	0006	Cylinder Shutoff
0007	Idle Speed Initialization	0008	Canister Control Valve
0009	Distributor Adjustment	0010	System Parameter
0011	Engine Test	0012	End-of-Line Test
0013	Bleeding Mode	0014	Matching Function
0015	Write VIN	0016	Match Key
0017	Read Network Configuration	0018	Function Configuration
0019	System Configuration	0020	Write Network Configuration (Manual)
0021	Write Fuel Injector Code	0022	User Authorization Code Setting
0023	Anti-theft Matching Function	0024	Input Code
0025	Immobilizer Matching	0026	Read Fuel Injector Code
0027	0ilMatch	0028	Read Network Configuration Information
0029	Write Network Configuration Information (Automatic)	0030	Network Configuration(Manual)
0031	Read EBS Information	0032	Write Battery ID No.
0033	Read Pedal Information	0034	Read Battery Information
0035	Clear Motor Start Times	0036	ReadStart-StopTimes
0037	Write Fuel Injector Code (All)	0038	Write Fuel Injector Code (Separate)
0039	Key Learning	0040	Steering Sensor Calibration
0041	Readand Write Network Configuration	0042	Match Key
0043	Write User Authorization	0044	Match EntireSystem
0045	Replace Engine ECM	0046	Program Engine VIN
0047	Reset Engine, Immobilizer	0048	Clear Key List
0049	Clear Adaptation Value	0050	Special Function
0051	Tooth Correction Error Learning	0052	Routine Control
0053	Longitudinal Acceleration Calibration	0054	DPF
0055	Tire Pressure Sensor Learning	0056	Manual Bleeding
0057	End-of-Line Configuration	0058	IMU Static Calibration
0059	Write Four-Wheel Tire Pressure Sensor ID	0060	Reset Adaptive Value
0061	Write Network Topology Information	0062	Reset Service Mileage
0063	Reset Mileage	0064	Horizontal Zero Point Calibration
0065	Rain Sensor Initialization Routine	0066	IUPR
0067	Yaw Angle Sensor Calibration	0068	Aftermarket Function
0069	FPAS Configuration (Manual)	0070	FPAS Configuration (Automatic)
0071	EGR Clear Self-Learning	0072	TCU RESET
0073	Write-in TSN Code	0074	Write Filling Status
0075	Return Circuit Configuration	0076	LCD Image Distortion (WOW)
0077	Maintain interval setting	0078	Remote matching
0079	Sensor Calibration	007A	Write function configuration
007B	Clear Adaptive Values	007C	Longitudinal Acceleration Calibration
007D	Write Data	007E	Parameter Adjustment
007F	Gateway reset	0080	RPAS configuration (manual)
0081	RPAS configuration (automatic)	0082	Disable Autostop Condition