

# MaxiSys\_ZOTYE\_V2.10 Function List (Note:For reference only)

## Notes:

● indicates the function is supported ※ indicates the function may be supported according to actual vehicle conditions

○ indicates the function is not available ▲ indicates the function is newly added to the newest version

Refer to Special Function List for special functions

Model	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
2008/5008	Engine System	UAES M797 Engine System	●	●	●	●	○	●	
2008/5008	Engine System	UAES EOBD Engine Syste	●	●	●	●	●	●	0012 0013 0014 0015 0016
2008/5008	Engine System	Marelli 03 Engine	●	●	●	●	○	●	
2008/5008	Engine System	Delphi EOBD Engine System	●	●	●	●	●	●	0017
2008/5008	ABS	Yatai ABS System	●	●	●	●	●	●	0004 0005 0006 0007 0008 0009
2008/5008	ABS	Delphi DBC7.8 System	●	●	●	●	●	●	
2008/5008	SRS	Delphi SRS	●	●	●	●	○	●	
2008/5008	SRS	Bosch Airbag 10 System	●	●	●	●	○	○	
2008/5008	Automatic Transmission System	Rongda CVT System	●	●	●	●	○	●	
2008/5008	Keyless Diagnostic	Zotye Keyless Learning	●	●	●	●	○	●	0018 0019 0020
Langlang	Engine System	UAES ME788 System	●	●	●	●	●	●	
Langlang	ABS	Bosch ABS 8.0	●	●	●	●	●	●	
Langlang	SRS	Bosch Airbag 10 System	●	●	●	●	○	○	
Langlang	Automatic Transmission System	Siemens AT Transmission	●	●	●	●	○	●	
Langlang	Keyless Diagnostic	Zotye Keyless Learning	●	●	●	●	○	●	0018 0019 0020
Langlang	Instrument Panel System	Zotye Combination Instrument Diagnosis-	○	○	○	●	○	○	
Langyue	Engine System	UAES ME788 System	●	●	●	●	●	●	
Langyue	ABS	Bosch ABS 8.0	●	●	●	●	●	●	
Langyue	SRS	Bosch Airbag 10 System	●	●	●	●	○	○	
Langyue	Automatic Transmission System	Dongan F4A4 Transmission System	●	●	●	●	○	○	
Langjun	Engine System	4A91 UAES Engine System	●	●	●	●	○	●	0021
Langjun	Automatic Transmission System	Automatic Transmission	●	●	●	●	○	●	
Langjun	ABS	BOSCH ABS	●	●	●	●	○	●	
Langjun	SRS	BOSCH Airbag	●	●	●	●	○	○	0021
Langjun	BCM	Body Control System	●	●	●	●	○	●	
Langjun	Instrument Panel System	Instrument Cluster	●	●	●	●	○	●	
Langjun	Immobilizer	Immobilizer	●	●	●	●	○	○	
Mutiplan	Engine System	Engine System	●	●	●	●	○	●	
Z100	Engine System	4A91 UAES Engine System	●	●	●	●	○	●	0021
Z100	ABS	BOSCH BS	●	●	●	●	○	●	
Z100	Electric Power Steering	Electric Power Steering	●	●	●	○	○	○	

Model	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
Z100	SRS	BOSCH Airbag	●	●	●	●	○	○	0021
Z100	Instrument Panel System	Instrument Cluster	●	●	●	●	○	●	
Z100	Immobilizer	Immobilizer	●	●	●	●	○	○	
Z300	Engine System	UAES Engine System	●	●	●	●	○	●	
Z300	ABS	BOSCH ABS 9	●	●	●	●	○	○	
Z300	SRS	BOSCH FL Airbag	●	●	●	●	○	○	0022
Z300	Instrument Panel System	ATECH Instrument Cluster	●	●	●	●	○	●	0023
Z300	BCM	ATECH Body System	●	●	●	●	○	●	0023
Z300	Immobilizer	Siemens Immobilizer	●	●	●	●	○	○	0024
Z300	ESP	Bosch ESP 9	●	●	●	●	○	○	0025
Z500	Engine System	4A91T UAES ME788 Engine System	●	●	●	●	●	●	0021 0026
Z500	Automatic Transmission System	CVT	●	●	●	●	○	●	0023
Z500	ABS	DBC 1200 Brake Control System	●	●	●	●	○	○	0025 0027
Z500	SRS	BOSCH Airbag	●	●	●	●	○	○	0023
Z500	BCM	ATECH B11 Body System	●	●	●	●	○	●	0026 0028
Z500	Keyless Start System	NAEN Keyless One-key Start System	●	●	●	●	●	●	0026 0029
Z500	Electric Power Steering	Electric Power Steering	○	●	●	○	○	○	
Z500	EPB	L.B.N Brake System	○	●	●	●	○	●	
Z500	Instrument Panel System	ATECH Instrument Cluster	●	●	●	●	○	●	0029 0030
T200	Engine System	UAES Engine System(EOBD)	●	●	●	●	○	●	0021
T200	Engine System	UAES M797 Engine System	●	●	●	●	○	●	
T200	Engine System	Marelli Engine System	●	●	●	●	○	●	
T200	Engine System	Delphi Engine System(EOBD)	●	●	●	●	○	●	
T200	Automatic Transmission System	Rongda CVT	●	●	●	●	○	○	
T200	ABS	Delphi ABS	●	●	●	●	○	●	
T200	ABS	Zhejiang Asia-pacific ABS	●	●	●	●	●	●	0004 0005 0006 0007 0008 0009
T200	SRS	BOSCH Airbag	●	●	●	●	○	○	0021
T200	SRS	Delphi Airbag	●	●	●	●	○	●	
T200	Immobilizer	Immobilizer(IMMO)	●	●	●	●	○	●	
T600	Engine System	1.5T Engine System	●	●	●	●	○	●	0021
T600	Engine System	2.0T M64TN Engine System	●	●	●	●	○	●	0021
T600	Automatic Transmission System	A/T	●	●	●	●	○	○	
T600	ABS	ABS	●	●	●	●	○	○	
T600	SRS	SRS	●	●	●	○	○	●	0021
T600	BCM	BCM	●	●	●	●	○	●	0026 0028
T600	Instrument Panel System	Instrument Cluster	●	●	●	○	○	●	
T600	Immobilizer	Immobilizer(IMMO)	●	●	●	●	○	○	
T600	Keyless Start System	NAEN Keyless One-key Start System	●	●	●	●	●	●	0021 0026 0029

Model	System	ECU	Retrieve ECU Info.	Read DTCs	Clear DTCs	Read Live Data	Read Freeze Frame	Active Test	Special Function
T600	TPMS	TPMS	●	●	●	●	○	○	
T600	ALS	ALS	○	●	●	○	○	○	
T600	Gateway System	Gateway System	●	●	●	●	○	○	0021
T600	EPB	L.B.N Brake System	○	●	●	●	○	●	
T600	Electric Power Steering	Electric Power Steering	○	●	●	○	○	○	
V10	Engine System	UAES Engine System	●	●	●	●	○	●	0021

## Special\_Function

Index	Special Function Name	Index	Special Function Name
0001	Vehicle Configuration	0002	Set the parameters
0003	Fault diagnosis	0004	Custom list
0005	Coding	0006	Adaption
0007	Basic Setting	0008	Security Access(Login)
0009	Single Reading	0010	Parameter adjustment
0011	Automatic Bleeding	0012	System Status
0013	I/M Readiness	0014	O2 Sensor Test
0015	On-Board Monitor Test	0016	Vehicle Info
0017	Restore Default	0018	Learn Remote Control ID
0019	Learn Immobilizer ID	0020	Learn Remote Control TransponderID
0021	Write VIN	0022	Airbag Config
0023	Write Data	0024	Match Function
0025	Bleeding Function	0026	ECU Reset
0027	Vacuumpumping Function	0028	Remote controller match and reset
0029	System learning	0030	Service Reset